

# ASSEMBLY INSTRUCTIONS


MODEL:BE1026C-CH

Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratcheds. Refer steps provided as assembling guide.


PART LIST		
ITEM	DESCRIPTION	QTY
A	Chair Leg	4 PCS
B	Footrest	1 PC
C	Apron	1 PC
D	Cushion Seat	1 PC
E	Backrest	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC Screw M6 x 25mm	4 PCS
2	JCBC Screw M6 x 40mm	8 PCS
3	JCBC Screw M6 x 45mm	6 PCS
4	Spring Washer M6 x 13mm	14 PCS
5	Flat Washer M6 x 16.5mm	14 PCS
6	Allen Key M4 x 110	1 PC


## STEP 1



Attach each leg (A) to footrest (B).  
(DO NOT TIGHT ANY SCREWS COMPLETELY!)




## STEP 2




Attach each leg (A) to apron (C).  
(TIGHT UP THE SCREWS COMPLETELY IN STEP 1 AND STEP 2!)

## STEP 3




Tight the cushion seat (D) with backrest (E) together.

## STEP 4



Tight up the chair leg and chair seat together.

## STEP 5



COMPLETE ASSEMBLY